

Widespread Lavatory Faucet Installation Instructions

CALIFORNIA FAUCETS RECOMMENDS THAT ALL PLUMBING PRODUCTS BE INSTALLED BY A LICENSED PROFESSIONAL

IMPORTANT: Read all instructions prior to installation and provide copy of instructions to consumer.

Operating Specifications:

Recommended Supply Pressure: 20 to 70 psi*†

Maximum Flow Rate: 1.2 gpm

* Operating pressures between hot and cold supplies should vary no more than 30 psi.

† If water pressure exceeds 70 psi, install a Pressure-Reducing Valve (PRV).

I


INSTALLING SPOUT

- Attach RING (2) onto BASE (3)
- Insert spout SHANK (1a) through BASE (3) and center hole in sink

NOTE: Sink / Deck recommended hole size is Ø1-3/8"

- Place slotted WASHER (4) onto spout SHANK (1a) and tighten SPOUT (1) into place with NUT (5)
- Insert RUBBER WASHER (6) into TEE (7) and attach to spout SHANK (1a)

IMPORTANT: TEE (7) should be tightened to create watertight seal and positioned to allow ease of attachment of valve hoses



INSTALLING VALVE

- From underneath, insert VALVE (8) through appropriate sink/deck hole

IMPORTANT: VALVES (8) are labeled as follows:

BLUE is **COLD** left turning (counter-clockwise) closed



RED is **HOT** right-turning (clockwise) closed

- Position flange NUT (9) and WASHER (10a) so that VALVE (8) extends above sink/deck surface according to table below
- Secure VALVE (8) with TOP NUT (11) and WASHER (10b) noting correct TOP NUT (11) orientation



IMPORTANT: TOP NUT (11) **MUST** have flat side towards deck

- Attach RING (12) onto ESCUTCHEON (13)
- Place ESCUTCHEON (13) onto VALVE (8) and secure to sink/deck surface

Series	A
44	2-3/4"
45	2"
45X	2"
48	2-3/8"
48X	2-5/16"
65	1-15/16"
66	1-15/16"



TOP NUT (11)
flat side down



3



INSTALLING HANDLES

- Loosen SETSCREW (14b) from HANDLE (14a)
- Slide HANDLE (14) down onto and engage valve STEM (8a)
- Allow a minimum gap (1/32") between HANDLE (14) and ESCUTCHEON (13), tighten SETSCREW (14b)

IMPORTANT: To obtain proper alignment it may be necessary to rotate VALVE (8) so that HANDLE (14) is aligned to desired orientation

- Attach small hose NUT (15a) to spout TEE (7a)
- Attach large hose NUT (15b) to valve side OUTLET (8b)
- Repeat on other side valve

NOTE:
INSTALL WASHER
UNDER HANDLE(S)
TO ACHIEVE PROPER
GAP BETWEEN
HANDLE AND
ESCUTCHEON



4

INSTALLING SUPPLY LINES

IMPORTANT: Prior to attachment, flush supply lines to remove debris that may cause damage or malfunction to valve cartridge.

The following are two types of supply lines (not included) that may be installed to the valve bodies:


Bullnose riser for exposed application

- Install BULLNOSE RISER (16a) using valve NUT (8c) to secure riser to valve INLET (8b)

-OR-

Flexible riser for non-exposed application

- Discard valve NUT (8c) & install FLEX RISER (16b) to valve INLET (8b)



5

INSTALLING DRAIN

- Slide white foam WASHER (17) up under flange of BODY (18)
- or -
Apply thin film of silicone caulk (or equivalent) to underside of flange on BODY (18)
- Insert BODY (18) down through sink drain hole
- From underside, slide MACK-WASHER (19) and FRICTION-WASHER (20) up onto BODY (18)
- Secure BODY (18) into place with flange NUT (21)
- Apply thread sealant to threads on TAILPIECE (22) & tighten onto BODY (18)

Final connections

- Attach drain tailpiece to p-trap (not supplied)
- Turn on water supply valves and check for leak

