

# UNIVERSAL FLUSH VALVE

## Installation Instructions:

### REMOVE TOILET TANK

1. Shut off water supply to toilet tank.
2. Disconnect water supply.
3. Remove nuts washers and bolts.
4. Lift tank off bowl.
5. Remove sponge gasket.
6. Remove mounting nut with a wrench.
7. Remove old flush valve.

### FLUSH VALVE AND TANK TO BOWL GASKET INSTALLATION

1. Install new flush valve, Rubber seal inside, washer on underside of tank. Hand tighten nut.
2. Place sponge gasket over mounting nut.
3. Place tank on bowl and assemble hardware.
4. Tank will wobble initially. Apply downward pressure to tank with hand to keep tank level. Alternate tightening each hex nut until tank is stable and level.
5. Use adjustable wrench to tighten hex nuts if needed. Do not continue tightening if tank and bowl touch. Do not overtighten as the tank may crack.
6. Connect chain to flush lever, adjust its length long enough to seat/seal against flush valve seat surface.

# VÁLVULA DE DESCARGA UNIVERSAL

## Instrucciones de Instalación:

### DESMONTE EL TANQUE DEL INODORO

1. Corte el suministro de agua.
2. Desconecte el suministro.
3. Retire las tuercas, las arandelas y los pernos.
4. Retire el tanque levantándolo de la taza.
5. Retire el empaque de esponja.
6. Retire la tuerca de montaje con una llave.
7. Descarte la válvula de descarga

### INSTALACIÓN DE LA VÁLVULA DE DESCARGA Y EMPAQUE TANQUE A TAZA

1. Instale la nueva válvula de descarga del inodoro. Deje la junta de goma en el interior y la arandela en la parte inferior del tanque. Apriete la tuerca con la mano.
2. Coloque el empaque de esponja sobre la tuerca de montaje.
3. Coloque el tanque sobre la taza e instale la tornillería.
4. Al principio el tanque oscilará. Aplique presión con la mano hacia abajo del tanque para mantenerlo nivelado. Alterne el apriete de las tuercas hexagonales hasta que el tanque esté estable y nivelado.
5. Utilice una llave inglesa para apretar las tuercas hexagonales. No siga apretando si el tanque y la taza se tocan. No apriete demasiado ya que el tanque podría agrietarse.
6. Conecte la cadena en la palanca, ajustar su longitud lo suficiente para asentar/sellar contra la superficie del asiento de la válvula de descarga.

