

TUBE CUTTER COUPE-TUYAU CORTADOR DE TUBOS

3/16" to 1 1/8" o.d. copper / cuivre d.e. 5 mm à 29 mm /
cobre d.e. 5 mm a 29 mm

CUTTING

1. Place tubing between rollers ❶ and cutter wheel ❷. Tighten knob ❸.
▲ Do not overtighten.
2. Rotate 360° around tubing.
3. Continue to tighten knob ❸ slightly and rotate.

REAMING

1. Turn point ❹ out.
2. Insert point ❹ into tubing and rotate.

COUPE

1. Placer le tube entre les rouleaux ❶ et le couteau rotatif ❷.
Serrer le bouton ❸.
▲ Ne pas serrer trop fort.
2. Rotatif 360° autour du tube.
3. Continuer de serrer légèrement le bouton ❸ et tourner.

ALESAGE

1. Tourner la pointe ❹ en dehors.
2. Insérer la pointe ❹ dans le tube et tourner.

CORTAR

1. Coloque el tubo entre los rodillos ❶ y la rueda cortadora ❷.
Apriete la perilla ❸.
▲ No apriete demasiado.
2. Gire 360° alrededor del tubo.
3. Siga apretando ligeramente la perilla ❸ y continúe girando.

AGRANDAR

1. Coloque la punta ❹ hacia afuera.
2. Introduzca la punta ❹ en el tubo y gírela.

