

Instructions for installing the Flex450 Bath Waste Assemblies

NOTE: THIS PRODUCT SHOULD NOT NEED TO BE STRETCHED OR COMPRESSED TO FIT THE TUB. IF IT DOES NOT FIT EASILY, CALL THE FACTORY TO GET THE CORRECT SIZE FOR THAT TUB.

Step 1: Secure the drain tee (*Item 7a*) and drain flange gasket (*Item 6*) under the tub by screwing in the strainer body (*Item 5*) through the tub drain hole from the inside the tub.

Step 2: Cut the pipe to the desired length. Place the overflow foam gasket (*Item 8*) onto the overflow elbow (*Item 7b*). **Step 3:** Insert overflow elbow and foam gasket assembly into the tub overflow hole from the back of the tub.

Step 4: Screw on the retainer nut (*Item 9*) from inside the tub. **HAND TIGHTEN ONLY.**

If not testing the bath waste, skip to Step 6.

Step 5: Screw the strainer test plug (*Item 11*) into the strainer body (*Item 5*) and test the system. Once testing is complete, remove the strainer test plug (*Item 11*). **Step 6:**

Cut away the orange test membrane from the overflow elbow (*Item 7b*). **Step 7:** Snap on the overflow plate (*Item 10*) with slot facing downward.

Step 8: Install stopper assembly (*Items 1-4*) into the strainer body (*#5*). *Note: Items #1 thru #4 may vary depending on the type of stopper assembly being used.*

