
American Standard Portsmouth® Pull-Down Bar Thank you for selecting American Stand the benchmark of fine quality for over 14 To ensure that your installation process these instructions carefully before your	10 years. eds smoothly-please read	
RECOMMENDED TOOLS		
Flat Blade Screwdriver Phillips	Screwdriver Adjustable Wrench	Plumbers' Putty or Caulking
1 INSTALL FAUCET WITH OR WITHO	OUT DECK ESCUTCHEON CAUTION	Turn off hot and cold water supplies before beginning.
<ul> <li>(A) Installation ESCUTCHEON (1). Apply a bead of putty to bottom edge of ESCUTCHEON with PUTTY PLATE (1). Make certain the SEAL (9) is properly seated in recess of faucet body. Insert SUPPLY HOSES (2), SPRAY HOSE (7) and SHANK (3) through hole of ESCUTCHEON with PUTTY PLATE (1) and mounting surface. Follow mounting instructions below to secure faucet to mounting surface</li> <li>(B) Installation less ESCUTCHEON (1). Discard ESCUTCHEON with PUTTY PLATE (1). Make certain the SEAL (9) is properly seated in recess of RING BASE (10). Insert supply HOSES (2), SPRAY HOSE (7) and SHANK (3) through mounting hole and seat RING BASE (10) onto sink or mounting surface. Do not use putty.</li> <li>Insert HOSES (2) through RUBBER WASHER (4), BRASS WASHER (5), and threaded LOCKNUT (6).</li> <li>Assemble RUBBER WASHER (4), BRASS WASHER (5), and threaded LOCKNUT (6) onto SHANK (3) from underside of sink or mounting surface. Hand tighten LOCKNUT (6).</li> </ul>		
Use a screwdriver to tighten SCREWS (screws slightly each time until all are snull and spour base of the spour base	a) on LOCKNUT (6). Work your way around LO g to ensure even pressure.	

## <sup>2</sup> MAKE WATER SUPPLY CONNECTIONS

- Turn off hot and cold water supplies before beginning.
- Connect FLEXIBLE SUPPLY HOSES (1, 2) directly to wall supplies. Connection on fitting supplies are 3/8" compression. Connect left supply hose (Red Stripe) to Hot wall supply. Connect right supply hose (Blue Stripe) to Cold wall supply. Use adjustable wrench to tighten connections. Do not over tighten.
- \* Faucet supplies are 21" long from faucet base.
- Note: If additional supply length is required, installer must purchase additional parts separately.
- Important: If SUPPLY HOSES (1, 2) are too long, loop as illustrated to avoid kinking.



## 24" (610mm) 6 4 5

REMOVE

## **3** CONNECT SPRAY HOSE AND INSTALL WEIGHTS

- Push the SPRAY HOSE END (1) into the HOSE CONNECTOR (2) slide down LOCKING COLLAR (3) until it snaps into place to secure connection.
- With hand spray seated in spout, install WEIGHT (4) onto HOSE (5) 24 inches from the underside of the sink deck and secure with LATCH (6).



- With HANDLE (1) in "off" position.
- Turn ON water at main supply.
- Check connections for leaks. (See Section 5)
- With HANDLE (1) in "off" position, unthread SPRAY (3) from HOSE (2).

3

- Operate handle back to front, in COLD and HOT positions, to flush water lines thoroughly.
- Replace SPRAY (3) onto HOSE (2).

## 4a SPRAY OPERATION

• With FAUCET on pull down SPRAY (3). Check for leaks. Make sure SPRAY (3) fully retracks and is seated in the SPOUT HOLDER (4).

