

INSTALLATION INSTRUCTIONS

TOOLS NEEDED:



DO NOT USE:



1. Insert bolts, head down, into mounting adjustment slots on floor flange.
2. Slide plastic retainer washer down threads to hold bolts in place. Place a new wax gasket (sold separately) onto bottom of toilet bowl.
3. Line up holes in toilet base with bolts in floor flange. Place toilet on top of flange.
4. Place brass washer, then nut on bolt. Carefully tighten. **DO NOT OVERTIGHTEN** or bowl may crack.

If new bolt caps are needed, use Fluidmaster Model 7115 or 7116.

