



MAIDSTONE

Showerhead Installation Guide

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We are providing guidelines for a standard installation as we cannot account for the individuality of the site or items you may be working with.

1. Use Teflon tape on the threaded end of the exposed upper riser tubing or the in wall shower arm (not included with showerhead).
2. Screw on the showerhead and hand tighten.