

# TUB SPOUT BEC DE BAIGNOIRE SURTIDOR DE BAÑERA



**1/2" x 3 - 1/4" coarse thread / filetage normal 13 mm x 8 mm / rosca gruesa 13 mm x 8 mm**

1. Apply thread seal tape to pipe extending from wall ②.  
▲ Do not use pipe joint compound.
2. Hand tighten spout ① onto pipe.
3. If spout ① does not fit snug against wall, replace pipe.

1. Appliquer du ruban d'étanchéité au tuyau qui continue au-delà du mur ②.  
▲ N'utiliser pas de ciment pour joints.
2. Resserrer le bec ① sur le tuyau.
3. Si le bec ① ne va pas bien contre le mur, remplacer le tuyau.

1. Aplique cinta de sellado de roscas al tubo saliente de la pared ②.  
▲ No use compuesto para unir tubos.
2. Apriete a mano la salida ① en el tubo.
3. Si la salida ① no ajusta completamente contra la pared, reemplace el tubo.

