

## TOILET BOLTS & SCREWS BOULONS ET VIS DE PLANCHER POUR TOILETTE TORNILLOS Y PERNOS DE PISO DE INODORO

**bolts - 5/16" x 2 - 1/4", screws - 1/4" x 2 - 1/2"    boulons - 8 mm x 57 mm, vis - 6 mm x 64 mm**  
**pernos - 8 mm x 57 mm, tornillos - 6 mm x 64 mm**

### BOLT

1. Place bolts ❶ on flange and set toilet over bolts.
2. Place washers ❷ and nuts ❸ onto bolts.
3. Tighten nuts.

### SCREW

1. Drill 3/16" holes, assemble washers ❹ and nuts ❺ onto screws ❻.
2. Insert screws ❻ into holes and tighten nuts until snug.

### BOULON

1. Placer les boulons ❶ sur la flasque et asseoir la toilette sur les boulons.
2. Placer les rondelles ❷ et les écrous ❸ sur les boulons.
3. Serrer les écrous.

### VIS

1. Percer des trous de 5 mm, assembler les rondelles ❹ et les écrous ❺ dessus les vis ❻.
2. Insérer les vis ❻ dans les trous et serrer les écrous jusqu'à ce qu'ils soient ajusté.

### PERNO

1. Coloque los pernos ❶ en la chapetón y asiente el inodoro sobre los pernos.
2. Coloque las arandelas ❷ y tuercas ❸ en los pernos.
3. Apriete los pernos.

### TORNILLO

1. Perfore hoyos de 5 mm, ensamble las arandelas ❹ y tuercas ❺ en los tornillos ❻.
2. Inserte los tornillos ❻ en los hoyos y apriete las tuercas hasta que queden ajustadas.

**CONTENTS:** 4 Nuts, 4 Washers, 2 Bolts, 2 Screws

**CONTENU:** 4 Écrous, 4 Rondelles, 2 Boulons, 2 Vis

**CONTENIDO:** 4 Tuercas, 4 Arandelas, 2 Pernos, 2 Tornillos

