

Installation Instructions

How to Install Tub Spout to Outlet Fitting
MODEL NO's: 10081, 2-564, 8-009, 8-030, 3-427

NEWPORT BRASS®

Flawless Beauty. From Faucet to Finish.™

This instruction illustrates how to install Newport Brass In-wall Tub Spout

We Recommend Installation by a Professional Plumbing Contractor

I. Spout Installation

1. **Figure 1**, for 1/2" NPT OUTLET FITTING thread FACE BUSHING 3/4" X 1/2" NPT to SPOUT. Use plumbers tape or equivalent to seal all threaded joints.
2. **Figure 1**, determine the proper length of NIPPLE to connect SPOUT to OUTLET FITTING. Use a temporary 6" length x 1/2" NPT NIPPLE to connect them together. Measure the GAP between the Finish Wall and the SPOUT BASE (including Base Ring where applicable). If length of the temporary NIPPLE is 6", and the GAP is 1", the proper length for the NIPPLE is 5" (6 - 1=5") to connect the SPOUT to OUTLET FITTING.

