

INSTALLATION INSTRUCTIONS

LEVER HANDLE

Model No: 3-368

NEWPORT BRASS

Flawless Beauty. From Faucet to Finish.™

Recommended Installation by a Professional Plumbing Contractor

Note: The use of petroleum base plumbers putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials.

I. Place O-RING (4) and ESCUTCHEON (2) over VALVE STEM (3). Secure handle assembly into place by first engaging the VALVE STEM (3), then position and holding the handle LEVER (5) while rotating the BONNET (1) and ESCUTCHEON (2). See illustrations below for variable application requirements.

