

INSTRUCTION GUIDE

WAX RING



1

After the Joni-bolts are placed in the desired location, dry fit the toilet to make sure the floor is level. (If it is unlevel shim appropriately.)

2

Remove the toilet and leave the shims in place, excess material can be cut off later. Place the wax seal onto the flange.

3

Set the toilet down with a small twist but no rocking.

4

Secure the Johni-bolts.

5

Cut the bolts to fit under the toilet bolt caps.

6

Once you have confirmed that your wax seal as created a water / air tight seal, caulk around the base of the toilet to eliminate bacteria growth under the bowl.

