



Installation Information

P0679 - 12" Support Brace

1. Assemble parts as shown below.
2. Measure from wall to supply line to get desired support length needed and cut only the non-threaded end of the rod accordingly. Re-install the C-clamp.
3. Attach the wall support escutcheon to the wall at desired height with the enclosed screws and anchors.
4. Attach the other side of the C-clamp and secure the two parts together with the supplied screws.

