



INSTALLATION GUIDE

Cixx Wall Mounted Lav or Tub Filler

Feb 2014



1. When disassembling the parts out of the box, pay close attention to how the handles work with the escutcheons. This will help when it's time to install the trim.
2. Install roughs with the following measurements from surface of finished wall:
 - Valves 1-11/16" from finished wall to tip of inner valve stem
 - Spout injector 1-1/8" from finished wall to tip of injector

3. Slide the stem extensions onto the end of the valve stems.

4. Holding the handle in the escutcheon, begin threading the escutcheon. Finish threading the escutcheon onto the valve stem, seating the handle.

Note: Hold the handle clocked to the desired position when installing the trim.

If it feels like there is binding when the stem extension engages the handle, carefully back it off and try again. If installed improperly, the stem extension may break over time.

5. Lubricate spout injector and install spout. Position spout and tighten set screw.



INSTALLATION GUIDE

Cixx Wall Mounted Lav or Tub Filler

Feb 2014

