



INSTALLATION INSTRUCTIONS

Cixx Shower Arm & Head
CX-SHW-HD

Feb 2014



Due to the weight of the Cixx Shower Arm & Head assembly, it is necessary that it be installed piece-by-piece, according to the following instructions.

1. Using the Allen wrench provided, loosen (do not remove) the two set screws (top & bottom) on the shower arm, releasing the injector.



2. Install injector onto a 3/4" or 1/2" nipple.
3. Apply additional lubrication if necessary, and carefully slide the shower arm onto the injector. Tighten the set screws using the Allen wrench provided.
4. Flush the line.



INSTALLATION INSTRUCTIONS

Cixx Shower Arm & Head
CX-SHW-HD

Feb 2014

5. Loosen (do not remove) the two set screws on the head. Protect the finished parts, and unscrew the "ball-joint keeper" from the head.



6. Apply Teflon tape to the threads on the ball joint. Using a 1/4" Allen wrench (not provided), thread the ball joint into the shower arm until secure.



7. Re-attach the CIXX Shower Head back on to the ball joint keeper, reversing the process in step 5. Remember to re-tighten the 2 set screws to secure the ball-joint & keeper.