


# Add-A-Rod™


/// 1" X 60" "D" Style Shower Rod

## Model 974-668303BH

Tools required for installation (not included):



Drill



Screwdriver (Phillips Head)



Adjustable Wrench

## Installation Instructions

1. Slip ceiling support loop (F) onto the 3/8" straight tube (B) with the inside set screw of the Ceiling support loop facing the mounting wall.
2. Insert swaged end of "L" sections (A) into ends of 38" straight tube (B)
3. Inset straight end of "L" sections through the two End loops (D) of the 53" straight tube (C). Allow the "L" sections (A) to protrude 1" beyond the End Loops (D) and secure in place with the set screws provided in the loops.
4. Slip the two shallow flanges (H) onto the protruding "L" sections, with light pressure.  
**Note: Bottom of flanges (H) must be flush with ends of protruding tubes.**
5. Secure the two shallow flanges (H) to the wall with the provided screws (J) and anchors by positioning the center of the shallow flange (H) 24 1/2" from ceiling. Secure flange to the wall with the provided screws (J) and anchors. Use extra care to keep assembly level.
6. Thread the 24" ceiling support rod assembly so that the ceiling support flange (G) and into the ceiling support loop (F).
7. Position the ceiling support rod assembly so that the ceiling support flange (G) is flush with the ceiling and the "D" style assembly is level.
8. Secure ceiling support flange (G) to the ceiling by using two of the screws (J) provided.
9. Tighten all screws.

