



FINE BATHROOM INTERIORS

Installation Instructions

Important: Please read these instructions before starting work.

1. Check that there are no buried pipes or cables before drilling holes. Take extreme care when using electrical equipment near water.
2. When mounting accessories onto a tiled surface, a piece of insulating tape applied to the surface will help to prevent drill slippage.
3. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
4. We recommend the use of a specialized drill bit when fixing accessories to tiled areas.

Supplied Mounting hardware:

Decorative concealment caps, cap threads, screws and wall plugs

Mounting Instructions:

1. Establish the position for the accessories, making sure there is sufficient room.
2. Position basket onto the wall and mark attachment holes with a pencil. Ensure the marks are horizontal by use of a carpenter's level.
3. Drill holes to a minimum depth of 1" inch using a 3/16" inch drill bit. Gently insert the wall plugs into the hole either by hand, or by gently tapping with a rubber mallet, until they are flush with the wall. If need be, carefully increase the diameter of the hole to accommodate the anchor. The anchor must fit snugly into the wall to assure a secure fixation of the mounting plate.
4. Add the cap thread to each screw.
5. Fix the basket onto the wall by securing the screws into the wall plugs. Tighten the screws, attach decorative caps to the cap threads and hand tighten.

Care Instructions:

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)

