

ASSEMBLY INSTRUCTIONS




Diagram 1

Diagram 2

Barrett 30" Linear Bath Light

Item # RL2117

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver	Slotted Screwdriver	Hammer
Pencil	Drill	

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Remove mounting plate (B) from fixture (E) by removing screws (D).
3. Using mounting plate (B) as a guide, line up with the junction box and mark anchor positions.
4. Using a drill bit slightly smaller than the anchor, drill holes in the marked positions. Install anchors (G) into the holes using a hammer.
5. Connect driver (H) input neutral wire (white) to the supply neutral wire (usually white) using wire nut (A).
6. Connect driver (H) input hot wire (black) to the supply hot wire (usually black) using wire nut (A).

CAUTION: Do not reverse the hot and neutral connections.


7. Insert driver (H) into junction box.
8. Install mounting plate (B) to the junction box and secure with mounting screws (C), then secure wood screws (F) to anchors (G).
9. Remove protective cap (O) from light source base and remove shade cap (J) from top cap (N) (see diagram 1).

NOTE: Discard protective cap (G) after assembly.

10. Place shade cap (J) onto glass shade (K), then insert light source (L) into glass shade (K).

RALPH LAUREN

ASSEMBLY INSTRUCTIONS



Barrett 30" Linear Bath Light

Item # RL2117

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

11. Thread light source **(L)** and glass shade **(K)** to shade cap **(M)**, then thread shade cap **(J)** to top cap **(N)**.
NOTE: Do not overtighten otherwise shade could become damaged.
12. Wrap supply ground wire (usually green or bare copper) around the green grounding screw (see diagram 2). Tighten.
NOTE: It is imperative that the fixture is grounded.
13. Connect quick connector **(I1 & I2)** together.
14. Make sure all wire connections are tight, then carefully tuck into the junction box.
15. Install fixture **(E)** to mounting plate **(B)** and secure with screws **(D)**.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

RALPH LAUREN