

access

LIGHTING

INSTALLATION INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

MESURES DE SECURITE A RESPECTURE

Before assembling your ACCESS LIGHTING fixture, please make sure that you carefully read through this instruction sheet. Save this instruction sheet and refer to it when additions to or changes in the fixture configuration are made.

Lisez attentivement ce manuel d'instructions. Enregistrer cette feuille d'instructions et de s'y référer lorsque les ajouts ou changements dans la configuration de montage sont faites.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.



COLLECTION

REVEAL

APPLICATION

Outdoor portable

MODEL NO.

20086LEDD

WHAT WE PROVIDE

- Charging Cable
- USB Wall Charger
- LED Lantern

1

CHARGING

Fully charge before first use (7-8 hours). When charging, the green indicator light will flash. When charging is completed, the green indicator light will stop flashing and remain on. Note the fixture may be charged while in the ON or OFF position. A red indicator light will slowly flash when battery is at 30% capacity.

2

PAIRING

When turned on, a Bluetooth pairing tone will chime. In your phone Bluetooth settings, connect to (Access Lighting Spkr). When paired, a second tone will chime indicating successful pairing. A disconnect tone will chime once the bluetooth device breaks connection with the fixture. Note, bluetooth connection will break when the battery voltage is lower than 3.4V and a red indicator light will flash. However, the fixture light may be used until 0% battery capacity.

3

LIGHT OPERATION

Your fixture has 3 light output setting. When the main switch is in the ON position, lightly touch the power button for low light setting. Touch a second and third time for medium and high setting. The fourth touch will turn the lamp off. Note, the speaker may still be used when the light is off.

4

BATTERY LIFE

4 hours use when used at maximum volume and light intensity.