

INSTALLATION GUIDE

quarto wall mount tub filler, deck mount lever control

BRUSHED NICKEL(BN)



CHROME(CH)









OPERATING SPECIFICATIONS

quarto wall mount tub filler, deck mount lever control



FEATURES

Waterfall Flow

OPERATING PRESSURE

Minimum: 15 psi Maximum: 75 psi

Above 90psi it may be necessary to install a pressure reducer

OPERATING TEMPERATURE


Maximum: 176°


FLOW RATE


10.0 USGPM




PRODUCT DIMENSIONS












artos®

F202-4









WESTOVER, INC

artos®


F202-4







artos

F202-4







STEP 8	1-1/2" HOLES THROUGH FINISHED WALL	



artos®

F202-4








PARTS BREAKDOWN

9

(12)


(13)

(14)





- 1 TUB FILLER MALE CONNECTOR F202-4 XP1
- (2) TUB FILLER SCREWS F202-4 XP2
- (3) BODY TO SPOUT SCREWS F202-4 XP3
- (4) TUB FILLER BODY F202-4 XP4
- (5) TUB FILLER GASKET F202-4 XP5
- (6) TUB FILLER SPOUT F202-4 XP6
- (7) SPOUT TO CONNECTOR SET SCREWS F202-4 XP7
- (8) **SET SCREW** F202-4 XP8
- (9) CONTROL HANDLE F202-4 XP9
- (10) CONTROL HANDLE ADAPTER F202-4 XP10
- (11) CONTROL DRESS RING F202-4 XP11
- (12) CONTROL CARTRIDGE SECURING NUT F202-4 XP12
- (13) CONTROL CARTRIDGE F202-4 XP13
- **14) CONTROL BODY** F202-4 XP14
- (15) CONTROL DECK GASKET UPPER F202-4 XP15
- **16 STAY BAR** F202-4 XP16
- 17 CONTROL DECK GASKET LOWER F202-4 XP17
- (18) MOUNTING BRACKET FLANGE F202-4 XP18
- (19) FLANGE SECURING NUT F202-4 XP19
- **20 O-RINGS** F202-4 XP20
- **(21) SUPPLY HOSES** F202-4 XP21





CARE & MAINTENANCE

quarto wall mount tub filler, deck mount lever control

For best results, keep the following in mind to retain the high quality finish of your $artos^*$ faucets:

- •Use a soft, dampened sponge or cloth. On no account should you use an abrasive material such as a brush, scouring pad or steel wool to clean surfaces.
- Test your cleaning agent solution on an inconspicuous area before applying to the entire faucet.
- Wipe surfaces clean and rinse completely with water immediately after applying cleaning agent.
- An ideal cleaning technique is to rinse faucet thoroughly and blot dry any water from the surface after each use.

LIMITED LIFETIME WARRANTY

Artos® Limited Lifetime Warranty

Artos® faucets have been manufactured under the highest quality and manufacturing standards. Artos® faucets are guaranteed for life against leaks and manufacturing defects for as long as the original consumer purchaser owns it. This warranty applies to installations in the US, Canada and Mexico (North America). Commercial, Industrial or business uses are warranted for a period of one year from the original date of purchase.

This warranty is non-transferable and applies exclusively to the original owner or end-user. If a defect is found during normal use, Artos® will, at its election, repair, replace or make an appropriate adjustment. Damage caused by accident, misuse, abuse, improper installation or alteration will void the warranty. This warranty does not cover replacement parts where damage is caused by normal wear and tear. Labor charges, installation or other incidental or consequential costs will not be covered.

Replacement parts that qualify for warranty repair can be obtained by contacting Artos® at 1-877-9ARTOS9 or by e-mail at info@artos.us.com. Proof of purchase (original sales receipt) from the original consumer purchaser must accompany all warranty claims. When submitting your claim in writing, please provide your name, address and telephone number.

Please register this product online at WWW.ARTOS.US.COM

Item No: **F202-4** Serial No: