F202ALT-9

quarto 2-hole deck mount tub filler, cubve control, open extended spout

BRUSHED NICKEL(BN)



CHROME(CH)



WHITE(WH)

POLISHED NICKEL(PN)





INSTALLATION GUIDE

F202ALT-9

quarto 2-hole deck mount tub filler, cubve control, open extended spout

OPERATING SPECIFICATIONS

FEATURES

Waterfall Flow

OPERATING PRESSURE

Minimum: 15 psi Maximum: 75 psi Above 90psi it may be necessary to install a pressure reducer

OPERATING TEMPERATURE

Maximum: 176°

FLOW RATE


6.0 USGPM 2.0 USGPM




F202ALT-9

quarto 2-hole deck mount tub filler, cubve control, open extended spout


PRODUCT DIMENSIONS






F202ALT-9


quarto 2-hole deck mount tub filler, cubve control, open extended spout



WESTOVER, INC 13305 B STREET OMAHA, NEBRASKA 68144 WWW.ARTOS.US.COM T:877.927.8679

INSTALLATION STEPS






WESTOVER, INC 13305 B STREET OMAHA, NEBRASKA 68144

WWW.ARTOS.US.COM T:877.927.8679

F202ALT-9

quarto 2-hole deck mount tub filler, cubve control, open extended spout





WESTOVER, INC

13305 B STREET OMAHA, NEBRASKA 68144

WWW.ARTOS.US.COM T:877.927.8679

INSTALLATION STEPS





WESTOVER, INC13305 B STREET OMAHA, NEBRASKA 68144WWW.ARTOS.US.COMT:877.927.8679

F202ALT-9

quarto 2-hole deck mount tub filler, cubve control, open extended spout

13) (1)14) 2 9 ́З` 15) 4 (16) 5 (1) SCREW CAPS F202ALT-2 XP1 (2) TUB FILLER SCREWS F202ALT-2 XP2 6 (17) (3) TUB FILLER BODY F202ALT-2 XP3 (4) TUB FILLER GASKET F202ALT-2 XP4 7 (5) TUB FILLER SPOUT F202ALT-2 XP5 (18) 8 (6) TUB FILLER SEAL UPPER F202ALT-2 XP6 (19) 9 (7) TUB FILLER CONNECTOR PLATE F202ALT-2 XP7 (8) SPOUT CONNECTOR F202-2 XP8 (10)(20) (9) TUB FILLER PLATE SCREWS F202ALT-2 XP9 (10) TUB FILLER SEAL LOWER F202ALT-2 XP10 21 (11)(11) TUB FILLER SECURING NUT F202ALT-2 XP11 (12) SET SCREW F202ALT-2 XP26 (13) CONTROL HANDLE F202ALT-2 XP27 23 (14) CONTROL HANDLE ADAPTER F202ALT-2 XP28 24 (15) CONTROL CARTRIDGE SECURING NUT F202ALT-2 XP29 (16) CONTROL CARTRIDGE F202ALT-2 XP30 (17)(18) CONTROL BODY F202ALT-2 XP31 (19) CONTROL DECK GASKET UPPER F202ALT-2 XP32 (20) STAY BAR F202ALT-2 XP33 (21) CONTROL DECK GASKET LOWER F202ALT-2 XP34 (22) MOUNTING BRACKET FLANGE F202ALT-2 XP35 (23) FLANGE SECURING NUT F202ALT-2 XP36 (24) O-RINGS F202ALT-2 XP37 (25) SUPPLY HOSES F202ALT-2 XP38

WESTOVER, INC

13305 B STREET OMAHA, NEBRASKA 68144

WWW.ARTOS.US.COM T:877.927.8679

12)

CARE & MAINTENANCE

artos

F202ALT-2

quarto 2-hole deck mount tub filler, cubve control, open extended spout

For best results, keep the following in mind to retain the high quality finish of your $artos^{\circ}$ faucets:

- •Use a soft, dampened sponge or cloth. On no account should you use an abrasive material such as a brush, scouring pad or steel wool to clean surfaces.
- Test your cleaning agent solution on an inconspicuous area before applying to the entire faucet.
- •Wipe surfaces clean and rinse completely with water immediately after applying cleaning agent.
- An ideal cleaning technique is to rinse faucet thoroughly and blot dry any water from the surface after each use.

LIMITED LIFETIME WARRANTY

$\exists \lceil t \mid 0 \leq \forall$ faucets are guaranteed for life against leaks and finishing defects for as long as the original purchaser owns it.

Damage caused by accident, misuse, abuse, improper installation, improper cleaning or alteration will void the warranty. This warranty does not cover replacement parts where damage is caused by normal wear and tear. Westover, Inc is not responsible for labor charges, installation or other incidental or consequential costs. Proof of purchase must be provided with all claims.

Please register this product online at WWW.ARTOS.US.COM

ITEM NO. **F202ALT-9** SERIAL NO.