


BALDWIN

ESTATE™

Installation Guide
Guía de instalación
Guide d'installation





baldwinhardware.com
800.566.1986

PK.1032 Rev 01 Door Knocker 0185


1 Center template on EXTERIOR side of door. Ensure template is level, and mark holes.

Centre la plantilla en la parte EXTERIOR de la puerta. Asegúrese de que la plantilla se encuentre nivelada y marque los orificios.

Centrer le gabarit sur la face EXTERIEURE de la porte. Assurez vous que le gabarit est bien aligné et marquez les trous.


2

3

Template

Plantilla

Gabarit

