

INSTALLATION INSTRUCTIONS

Tools Needed

- Pencil • Tube Cutter • Socket Wrench • Jigsaw • Wrench • Hammer • Screwdriver • Drill & 3/8" Bit •

Materials Needed

- Sink • Faucet • Drain Assembly • Supply Pipe & Fittings • Drain Pipe, Trap & Fittings • Silicone Sealant •

WARNING: We do not recommend cutting any countertops, especially granite, until you have the sink on the premises. Sizes vary slightly due to firing process.



Top View



End View

1. Using a template 1/2" narrower than the sink rim, mark the counter top cut out. Drill a starter hole 3/8" inside of circle and then use a saw to finish cutting the opening for the sink.
2. Place a bead of silicone caulk around the cut out opening. Before placing sink in place, attach the faucet, drain piece, flange and pop-up drain assembly. Set the sink into the opening. Press the rim down firmly. Hook up the drain and water supply fittings.
3. Tighten all connections, being careful not to over tighten. Check for leaks. Small leaks can be corrected by tightening the nuts.

NOTE:

DO NOT tighten too much or you may damage bowl.

INSTALLATION INSTRUCTIONS

Tools Needed

- Pencil • Tube Cutter • Socket Wrench • Saw • Wrench • Hammer • Screwdriver • Drill & 3/8" Bit •

Materials Needed

- Sink • Faucet • Drain Assembly • Supply Pipe & Fittings • Drain Pipe, Trap & Fittings • Silicone Sealant •

WARNING: We do not recommend cutting any countertops, especially granite, until you have the sink on the premises. Sizes vary slightly due to firing process.



Top View



End View

1. Using a template 1/2" narrower than the sink rim, mark the counter top cut out. Drill a starter hole 3/8" inside of circle and then use a saw to finish cutting the opening for the sink.
2. Attach the faucet, drain piece, flange, and pop up drain assembly to the sink. Place a bead of silicone caulk around the cut out opening. Set the sink into the opening. Press the rim down firmly. Hook up the drain and water supply fittings.
3. Tighten all connections, being careful not to over tighten. Check for leaks. Small leaks can be corrected by tightening the nuts.

NOTE:

DO NOT tighten too much or you may damage bowl.