



INSTALLATION INSTRUCTIONS


Tools You Will Need:




INSTALLATION STEPS:




1. Remove the mounting hardware from the faucet.




2. Place silicone sealant beneath the plastic gasket and install faucet through center hole.




3. Re-assemble the mounting hardware, screw and tighten lock nuts onto faucet.



4. Apply pipe tape to threads. Attach water supplylines on end to the faucet and screw onto inlet ports.



5. Connect to water supply.



6. After installing faucet, remove aerator assembly and open the hot and cold water supplies. Check for leaks. Turn on faucet handle for one minute to flush debris from faucet. Close the handles and re-assemble the aerator.