

Swag Hook

700TDSWG_

1.7


VISUAL COMFORT & CO.

ARCHITECTURAL COLLECTION


GENERAL PRODUCT INFORMATION:




This product must be used with Pendant fixtures only.




Mount the Swag Hook




- 1** Mark a point on the ceiling near the pendant fixture where the swag hook is to be mounted.
- 2** Tap the anchor at the marked point into the ceiling up to the threaded portion with a hammer.




- 3** Screw the anchor in the rest of the way with a Phillips screwdriver.




- 4** Mount the threaded washer to the anchor with the #8 screw.



- 5** Screw the swag hook onto the threaded washer.



- 6** Secure the swag hook to the threaded washer by tightening the small set screw.



- 7** Hook the fixture pendant wire into the swag hook and secure it in place by tightening the large set screw.

SAVE THESE INSTRUCTIONS!