Water Filter



This water filter removes chemicals and contaminants from your drinking water, resulting in clean tasting and clean smelling water. We recommend a new filter every six months for optimal water drinkability and flow. Use with Fisher & Paykel Refrigerator Models beginning with: E442, RF610, RF522, E402, RF201, RF402, RF135, RF170, RS36, RF540, RS9120, RF605, RS90, RS36, RS6121, RS7621, RS4621, RS3084, RS2484, RS1884 If you have an older refrigerator model you may need to use part no. 8462285 or 8462288. Please check your filter for the part number before purchasing

- Use with Fisher & Paykel Refrigerators, Model Numbers starting with: E442B, RF610A, E522B, RF522A, RF522W, E402B, RF201A, RF402B, RF522B, RF135B, RF170, RS36A, RF170B, RF540A, RS9120, RF605Q, RS90A, RS36A, RS36W
- Part number should be on the old Filter you are replacing.

SKU

847200

TEST The product dimensions and specifications in this page apply to the specific



A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 1.888.936.7872 Wwww.fisherpaykel.com

product and model. Under our policy of continuous improvement, these dimensions

and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model

currently available. ? Fisher & Paykel Appliances Ltd 2020