





ITEM	DESCRIPTION	PART NUMBER
1	CROSSBAR	XBR-MDS811
2	MOUNTING SCREW	SCR-MDS811-M
3	CHAIN	CHN-MDS811
4	FIXTURE ASSEMBLY	FAS-MDS811
5	SCREW COLLAR	SCL-MDS811
6	CANOPY	CPY-MDS811
7	SCREW COLLAR LOOP	SCL-MDS811-L
8	1/4 NIPPLE	NIP-MDS811
9	GROUND SCREW	SCR-MDS811-G
10	WIRE NUT	NUT-MDS811
11	PULL HOOK	HOK-MDS811
12	ALABASTER SHADE	ALA-MDS811
13	BULB	NOT INCLUDED
14	SMALL LOOP	HRD-MDS811
15	BALL NUT	HRD-MDS811
16	SILICONE WASHER	WAS-MDS811-S
17	BRASS WASHER	WAS-MDS811-B
18	END LOOP	LOO-MDS811-E

⚠ WARNING/CAUTION

- **DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.**
- **TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND MAINTENANCE OF THIS UNIT SHOULD BE COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED FACTORY TRAINED TECHNICIAN.**
- **CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.**
- **REMOVE THE FIXTURE, PARTS AND PARTS BAG(S) FROM THE CARTON. BEFORE DISCARDING THE CARTON, DOUBLE CHECK TO MAKE CERTAIN THAT ALL PARTS ARE FOUND. INSPECT THE FIXTURE PRIOR TO INSTALLATION FOR ANY DAMAGE TO THE FIXTURE.**
- **DIMMING: THE FIXTURE CAN BE CONTROLLED BY A WALL DIMMING DEVICE. ONLY USE TRIAC/ELECTRONIC DIMMER. MAKE SURE THE CARTON IS MARKED FOR USE WITH LED COMPACT FLUORESCENT-INCANDESCENT LIGHT SOURCE ONLY. THESE CAN BE PROVIDED BY YOUR LOCAL ELECTRICAL DISTRIBUTOR, HOME CENTER, OR HARDWARE STORE.**
- **PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS**

FIXTURE INSTALLATION

1. Attach the CROSSBAR (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
2. Open the end link on the CHAIN (3) and attach to the loop on the FIXTURE ASSEMBLY (4). Hang the FIXTURE ASSEMBLY (4) on the CHAIN (3) at your desired height, and remove excess CHAIN.
3. Feed the wire through the CHAIN (3), SCREW COLLAR (5), CANOPY (6), SCREW COLLAR LOOP (7), NIPPLE (8), and CROSSBAR (1), and screw the NIPPLE (8) onto the CROSSBAR (1).
4. Open the top link on the CHAIN (3), and Hang the FIXTURE ASSEMBLY (4) to the SCREW COLLAR LOOP (7).
5. Cut off excess wire, and strip the insulation off the end of the leads.
6. Attach the Ground wire (Green) to the ground inside the junction box (Generally green or bar copper wire) or the GROUND SCREW (9) on the MOUNTING PLATE (1). **NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!**
7. Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (10). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. **MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!**
8. Connect the black fixture leads to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. **NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!**
9. Push the wires back into the junction box. Lift up the CANOPY (6) up to the ceiling, and secure the SCREW COLLAR LOOP (7) onto the SCREW COLLAR (5).
10. Lift the ALABASTER SHADE (12) to the FIXTURE ASSEMBLY(4) then secure with the SILICONE WASHER(16),BRASS WASHER(17) and the END LOOP (18).
11. Hang one end of PULL HOOK(10) to the FIXTURE then secure the other end to the ALABASTER SHADE(12) using the SMALL LOOP(14) and BALL NUT(15).
12. Screw the BULB (13) up into the SOCKET of the fixture. **THIS FIXTURE IS RATED FOR 7 WATT LED LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!**
13. Restore power to the outlet at the breaker or fuse box.



ITEM	DESCRIPTION	PART NUMBER
1	CROSSBAR	XBR-MDS811
2	MOUNTING SCREW	SCR-MDS811-M
3	CHAIN	CHN-MDS811
4	FIXTURE ASSEMBLY	FAS-MDS811
5	SCREW COLLAR	SCL-MDS811
6	CANOPY	CPY-MDS811
7	SCREW COLLAR LOOP	SCL-MDS811-L
8	1/4 NIPPLE	NIP-MDS811
9	GROUND SCREW	SCR-MDS811-G
10	WIRE NUT	NUT-MDS811
11	PULL HOOK	HOK-MDS811
12	ALABASTER SHADE	ALA-MDS811
13	BULB	NOT INCLUDED
14	SMALL LOOP	HRD-MDS811
15	BALL NUT	HRD-MDS811
16	SILICONE WASHER	WAS-MDS811-S
17	BRASS WASHER	WAS-MDS811-B
18	END LOOP	LOO-MDS811-E

⚠ ATTENTION PRUDENCE

- DÉBRANCHEZ L'ALIMENTATION AVANT DE REMPLIR OU DE CÂBLER LE LUMINAIRE. LISEZ COMPLÈTEMENT TOUTES LES INSTRUCTIONS AVANT DE COMMENCER L'INSTALLATION
- POUR ÉVITER LE RISQUE D'INCENDIE OU D'ÉLECTROCUTION, LE LUMINAIRE DOIT ÊTRE INSTALLÉ CONFORMÉMENT À TOUS LES CODES ÉLECTRIQUES/DE CONSTRUCTION NATIONAUX ET LOCAUX APPLICABLES. L'INSTALLATION ET L'ENTRETIEN DE CET APPAREIL DOIVENT ÊTRE EFFECTUÉS PAR UN ÉLECTRICIEN AGRÉÉ OU UN TECHNICIEN CERTIFIÉ FORMÉ EN USINE.
- CALIFORNIE PROP 65 : CET APPAREIL D'ÉCLAIRAGE CONTIENT DES PRODUITS CHIMIQUES CONNUS PAR L'ÉTAT DE CALIFORNIE POUR PROVOQUER LE CANCER, DES MALADIES CONGÉNITALES ET/OU D'AUTRES DOMMAGES À LA REPRODUCTION. LAVER LES MAINS APRÈS UTILISATION.
- RETIRER LE LUMINAIRE, LES PIÈCES ET LE(S) SAC(S) DE PIÈCES DU CARTON. AVANT DE JETER LE CARTON, VÉRIFIEZ DOUBLE POUR VOUS ASSURER QUE TOUTES LES PIÈCES SONT TROUVÉES. INSPECTER LE LUMINAIRE AVANT L'INSTALLATION POUR TOUT DOMMAGE AU LUMINAIRE.
- GRADATION : LE LUMINAIRE PEUT ÊTRE CONTRÔLÉ PAR UN DISPOSITIF DE GRADATION MURALE. UTILISER UNIQUEMENT UN GRADATEUR TRIAC/ÉLECTRONIQUE. ASSUREZ-VOUS QUE LE CARTON EST MARQUÉ POUR UNE UTILISATION AVEC UNE SOURCE DE LUMIÈRE FLUORESCENTE À INCANDESCENTE COMPACTE UNIQUEMENT. CEUX-CI PEUVENT ÊTRE FOURNIS PAR VOTRE DISTRIBUTEUR ÉLECTRIQUE LOCAL, CENTRE À DOMICILE OU MAGASIN DE QUINCAILLERIE.
- VEUILLEZ NETTOYER UNIQUEMENT AVEC UN CHIFFON DOUX ET SEC ! N'UTILISEZ PAS DE NETTOYANTS

FIXTURE INSTALLATION

1. Attach the CROSSBAR (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
2. Open the end link on the CHAIN (3) and attach to the loop on the FIXTURE ASSEMBLY (4). Hang the FIXTURE ASSEMBLY (4) on the CHAIN (3) at your desired height, and remove excess CHAIN.
3. Feed the wire through the CHAIN (3), SCREW COLLAR (5), CANOPY (6), SCREW COLLAR LOOP (7), NIPPLE (8), and CROSSBAR (1), and screw the NIPPLE (8) onto the CROSSBAR (1).
4. Open the top link on the CHAIN (3), and Hang the FIXTURE ASSEMBLY (4) to the SCREW COLLAR LOOP (7).
5. Cut off excess wire, and strip the insulation off the end of the leads.
6. Attach the Ground wire (Green) to the ground inside the junction box (Generally green or bar copper wire) or the GROUND SCREW (9) on the MOUNTING PLATE (1). **NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!**
7. Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (10). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. **MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!**
8. Connect the black fixture leads to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. **NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!**
9. Push the wires back into the junction box. Lift up the CANOPY (6) up to the ceiling, and secure the SCREW COLLAR LOOP (7) onto the SCREW COLLAR (5).
10. Lift the ALABASTER SHADE (12) to the FIXTURE ASSEMBLY(4) then secure with the SILICONE WASHER(16),BRASS WASHER(17) and the END LOOP (18).
11. Hang one end of PULL HOOK(10) to the FIXTURE then secure the other end to the ALABASTER SHADE(12) using the SMALL LOOP(14) and BALL NUT(15).
12. Screw the BULB (13) up into the SOCKET of the fixture. **THIS FIXTURE IS RATED FOR 7 WATT LED LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!**
13. Restore power to the outlet at the breaker or fuse box.