

WASHING MACHINE HOSE TUYAU DE MACHINE À LAVER MANGUERA DE MÁQUINA DE LAVAR



**5' braided reinforced stainless steel / acier inoxydable renforcé et tressé de 5 pi /
acero inoxidable reforzado trenzado 5 pies**

INSTALLATION INSTRUCTIONS

- 1) Disconnect electrical power supply before servicing washing machine.
- 2) Turn off water supply to washing machine and disconnect old hose from faucet and washing machine.
- 3) Connect new hose, make certain connections are tightened at both ends.
- 4) Turn on water. Check for leaks.
- 5) Re-connect electrical power supply.

INSTRUCCIONES DE INSTALACIÓN

- 1) Desconecte el suministro de energía eléctrica antes de dar mantenimiento a la lavadora de ropa.
- 2) Cierre el suministro de agua a la lavadora de ropa y desconecte la manguera usada del grifo y de la lavadora de ropa.
- 3) Conecte la manguera nueva, verificando que las conexiones en ambos extremos estén apretadas.
- 4) Abra el agua. Compruebe si hay fugas.
- 5) Vuelva a conectar el suministro de energía eléctrica.

DIRECTIVES D'INSTALLATION

- 1) Débrancher la laveuse avant de la réparer.
- 2) Couper l'alimentation en eau de la laveuse et enlever l'ancien tuyau de raccordement entre le robinet et la laveuse.
- 3) Raccorder le nouveau tuyau en s'assurant que les raccords des deux extrémités sont bien serrés.
- 4) Ouvrir l'alimentation en eau. S'assurer qu'il n'y a aucune fuite.
- 5) Rebrancher la laveuse.

