




TempGuard™ HOT
Temperature sensor for disabling
fresh air damper in extreme heat

Specifications:

Off temp: 95°F +/- 5°
On temp: 4°F lower

2A @ 24VAC

Wiring Diagram



Installation:

Drill a 1/2" hole in duct on the hot air side of damper.

Fasten sensor with 2 self tapping screws provided.

Wire according to diagram.

TempGuard™ HOT
Temperature Sensor

ITEM NO. ACTG-H01



8 57702 00110 7



AirCycler
www.AirCycler.com