ASSEMBLY INSTRUCTION

2AGNL or C

THREE VALVE TUB & SHOWER



2AGNL




2AGNR


REMOVAL OF FIXTURE:


Always turn the water supply off before removing the existing fixture or disassembling a valve. Open all fixture handles to relieve water pressure and to ensure that the water has been successfully turned off.


CARE OF FIXTURE:


The use of warm water and a soft cloth is all that is required to clean Rubinet products. The patina of our living finishes (Oil Rubbed Bronze & Tuscan Brass) will change as a result of normal use. Applying Mineral Oil on occasion will create a softer look, subtle color changes and character.














HANDLE ALIGNMENT (2A)






3



Once cartridge valves are loose, screw them back into the faucet using the handle. Stop when you feel a noticeable resistance. Then remove handles.



Replace Left Handle (hot) **one tooth off** from the **OFF** position as shown.

And Right Handle (cold) **one tooth off** from the **ON** position as shown.

5



Turn the handles to the desired alignment. (This will unscrew the cartridge) This adjustment should not be more than 25°. LOCK NUT
Recommended torque 20Nm

Tighten Lock Nut using **17mm Deep Socket** wrench to secure cartridge valve position.

*Use handle to hold spline while tightening.


FEATURES:


- Brass construction with choice of 21 finishes
- Two Lever or Round handles, diverter (Lever or Round)
- Quarter turn Ceramic Disk cartridges
- Flow Rate


Shower : 7.0 gpm @ 50 psi Tub : 7.0 gpm @ 50 psi

APPROVAL:

- AB1953 / NSF61
- ASME A 112.18.1
- CSA B125.1







CONTACT US:

If you need assistance with installation, replacement parts or have any questions regarding your Rubinet product, please call a Customer Service representative at: 905-851-6781 toll free 1-800-461-5901 or visit **www.rubinet.com**