

Finish Line™ Adjustment Shims

Instructions

- 1 Remove the ring and strainer or cover (three screws) from the tilted fixture.
- 2 Locate the low side of the fixture and place the thick side of adjustment shim on the low side of the fixture.
- 3 Place ring and strainer or cover over shims and check for level. Add or remove shims as needed until fixture is level with finish floor.

Note: It may be possible to adjust the height by turning the fixture.

- 4 Align the ring and strainer or cover with brass inserts in the fixture head and re-install screws.
Use longer screw(s) as needed when using multiple shims.

