


ASSEMBLY INSTRUCTIONS



Frame Makers 30" Picture Light

Item # SL2708

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver	Slotted Screwdriver	Hammer
Pencil	Drill	

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Using fixture **(B)** as a guide, line up with the wall and mark anchor positions.
3. Using a drill bit slightly smaller than the anchor, drill holes in the marked positions. Install anchors **(A)** into the holes using a hammer.
4. Secure wood screws **(C)** to anchors **(A)**, leaving 1/8" of exposed thread in order to hang fixture.
5. Hang fixture **(B)** to wood screws **(C)**.
6. Loosen adjustment knobs **(D & E)** to adjust fixture arm and shade to desired angle, then adjustment knobs **(D & E)**.
7. Install light bulbs into the sockets.
8. Remove protective cover **(G)** from plug **(F)**.
9. Plug into electrical outlet and test the fixture.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.