


ASSEMBLY INSTRUCTIONS



Orsay Medium Floor Lamp

Item # PCD1200

NOTICE:

Inspect item carefully before attempting to install. If there is any damage or obvious defect, do not install. Item may not be returned once it has been installed.

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Remove protective sleeve **(F)** from cord.
3. Install rod **(C)** through the hole of to base **(D)** and loader **(E)**, then secure with metal washer **(G)** and hex nut **(H)**. Tighten using provided wrench.
4. Carefully feed wire through the slot of loader **(E)**.
5. Install light bulb into the socket.
6. Thread metal shade **(A)** to harp **(B)**.
7. Remove protective cover **(K)** from plug.
8. Plug into electrical outlet and test the fixture.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.