


ASSEMBLY INSTRUCTIONS



Orsay Medium Table Lamp

Item # PCD3200

NOTICE:

Inspect item carefully before attempting to install. If there is any damage or obvious defect, do not install. Item may not be returned once it has been installed.

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Install light bulb into the socket by lining up base to holes and twisting to secure.
3. Thread metal shade **(A)** to harp **(B)**.
4. Remove protective cover **(C)** from plug.
5. Plug into electrical outlet and test fixture.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.