







ITEM NAME/NOM D'ITEM: EMRYS DINING CHAIR


ITEM #/NO.ITEM: 101514

PART LIST / LISTE DES PIÈCES


(1)	(2)	(3)	(4)
 <p style="text-align: center;">x1</p>	 <p style="text-align: center;">x1</p>	 <p style="text-align: center;">x1</p>	<p>A  M6X35mm x3</p> <p>B  M6X25mm x4</p> <p>C  5mm x1</p>

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I



II



III



For missing parts or damaged parts, please call

USA : 1-866-798-6663

Canada : 514-382-6661