











ITEM NAME/NOM D'ITEM: BRAXTON DINING CHAIR
ITEM #/NO. ITEM: 101562/101563

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)
		
x1	x1	x1

(4)


A.  50mm x1	B.  M6 x 16mm x4	C.  5mm x1	D.  Ø6mm x8
E.  M6 x 50mm x4	F.  M6 x 16mm x4	G.  4mm x1	

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I.




II.



III.



IV.



V.



For missing parts or damaged parts, please call

USA : 1-866-798-6663

Canada : 514-382-6661

AI-4-200611