



















**ITEM NAME/NOM D'ITEM: ROCKY ARM CHAIR**

**ITEM # /NO.ITEM: 100528/100529/100530/101683/101684**

**PARTS LIST / LISTE DES PIÈCES**

(1)	(2)	(3)	(4)	(5)
				<ul style="list-style-type: none"> <li>A.  M8 x 60mm x2</li> <li>B.  Ø8mm x6</li> <li>C.  5mm x1</li> <li>D.  Ø8 x 18mm x2</li> <li>E.  Ø10 x 40mm x4</li> <li>F.  Wooden Cap x6</li> <li>G.  M8 x 80mm x4</li> <li>H.  4 x 50mm x2</li> <li>I.  Paste Pad x4</li> <li>J.  L - Bracket x2</li> <li>K.  4 x 20mm x4</li> <li>L.  Ø8mm x6</li> </ul>
x1	x1	x1	x2	

**ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE**



For missing parts or damaged parts, please call

USA :1-866-798-6663  
 Canada :514-382-6661