





ITEM NAME/NOM D'ITEM: WORCESTER DINING CHAIR


ITEM #/NO. ITEM: 101717/101718

## PARTS LIST / LISTE DES PIÈCES

(1)	(2)	(3)
 <p style="text-align: right;">x1</p>	 <p style="text-align: right;">x1</p>	<p>A.  M6x25mm x4</p> <p>B.  6mm x1</p>

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I.



II.



For missing parts or damaged parts, please call

USA : 1-866-798-6663

Canada : 514-382-6661

AI-2-200622