





ITEM NAME / NOM D'ITEM : DESI DINING CHAIR
ITEM # / NO. ITEM : 109730 (BROWN & WALNUT)

Enquiry : parts@zuomod.com

PARTS LIST / Liste des pièces

(1)	(2)	(3)
		1.  X4 M6*20mm 2.  X4 3.  X1

INSTRUCTIONS

	
--	--