AXENT

SWITZERLAND



AXENT.ONE C PLUS

E314

INSTALLATION INSTRUCTIONS

SAFETY SYMBOLS

The following warning signs warn you of dangerous situations and their severity:

DANGER!	High Risk, Lethal Hazards, Severe Injuries
WARNING!	Medium Risk, Severe Injuries
CAUTION!	Low Risk, Minor Injuries
NOTE!	Damage to Property

TARGET READERSHIP AND INSTALLER QUALIFICATIONS

Installation must be carried out by qualified professionals.
Repairs should only be performed by trained and qualified persons.

NOTE!

Follow all local installation regulations and country specific voltage and plumbing standards. DO NOT install the intelligent toilet in rooms where there is a danger of frost. The room temperature and water temperature must not be less than 4°C (39 °F).

Condensation may form when the intelligent toilet is brought from a cold location to a warm one. Leave the unit switched off for a few hours before operating.

DANGER!

Risk of fatal electric shock

The appliance must be grounded and plugged into a GFCI outlet.
DO NOT remove individual components from (inside of) the intelligent toilet.
If the unit has a damaged cord or plug, return the product to a service center for repair. The cord or plug may only be changed by qualified personnel.

CAUTION!

DO NOT reuse old hoses. Please use new hoses and included components.
Axent Corp is not liable or responsible for damaged caused by 3rd party components

TECHNICAL SUPPORT

For any questions or any assistance with this product, please contact your dealer or call us at
1-800-769-4857
support@axentproducts.com
www.axentbath.us

SCOPE OF DELIVERY

Standard delivery contents



Main body



12" Base Flange



Remote Control



Adhesive

User Manual





Bowl Mounting Hardware



Holder and Rubber plug



Installation Manual

Inlet Hose and Filter (Filter Adapter Requires 1/2" FIP Connection.)

Bowl Plug

Remote Control Mounting Hardware



Battery

Anti-theft Screws

The below parts are not included with the toilet.

Wax Ring



Bolts



Floor Mount

1 1



Please verify these dimensions before beginning installation.
These dimensions may vary in some locations.
Recommended operating pressure 40 - 80 psi.

2



Please run water until clear.

3



4



5



6



7



8



9



10



2 1



INSTALLATION

2





3





4



5



6



7



8



9



10



11



12



13 OPTIONAL

1



2



3



4



3

1

2

3



Please check for leaks before caulking.

4



Place serial number sticker here
for reference:

AXENT Corporation Ltd.

www.axentbath.us
support@axentproducts.com
1-800-769-4857

P/N: 224000033900 20-2.0