

artos[®]

F907-41

INSTALLATION GUIDE

flexible hose shower kit with
slide bar and separate water
outlet squ

BRUSHED NICKEL(BN)



CHROME(CH)



artos[®]

F907-41

OPERATING SPECIFICATIONS

flexible hose shower kit with
slide bar and separate water
outlet squ



FEATURES

Seperate Water Outlet
60" Flexible Hose

OPERATING PRESSURE

Minimum: 15 psi
Maximum: 75 psi
Above 90psi it may be necessary to install a pressure reducer

OPERATING TEMPERATURE

Maximum: 176°

FLOW CAPACITY

2.0 USGPM

INLET/OUTLET

1/2" Female NPT

REQUIREMENTS


This unit requires a control

artos[®]

F907-41

PRODUCT DIMENSIONS

flexible hose shower kit with
slide bar and separate water
outlet squ




F907-41

flexible hose shower kit with
slide bar and separate water
outlet squ


STEP 1 *ALL DIMENSIONS ARE APPROXIMATE

1-3/8" DIAMETER THROUGH
FINISHED WALL





STEP 2

1-3/8" DIAMETER
THROUGH FINISHED
WALL



INSTALLATION STEPS




artos[®]


F907-41

flexible hose shower kit with
slide bar and separate water
outlet squ



STEP 5





STEP 6




INSTALLATION STEPS



flexible hose shower kit with
slide bar and separate water
outlet squ



flexible hose shower kit with
slide bar and separate water
outlet squ



- ① WALL BRACKET SET SCREW F907-41 XP1
- ② SLIDE BAR F907-41 XP2
- ③ SLIDE BAR ADJUSTMENT HANDLE F907-41 XP3
- ④ HAND SHOWER HOLDER F907-41 XP4
- ⑤ HAND SHOWER HOLDER SCREW F907-41 XP5
- ⑥ SLIDE BAR INLET/OUTLET F907-41 XP6
- ⑦ ESCUTCHEON INLET/OUTLET F907-41 XP7
- ⑧ HOSE F907-41 XP8
- ⑨ WALL ANCHORS F907-41 XP9
- ⑩ WALL BRACKET F907-41 XP10
- ⑪ WALL BRACKET SCREWS F907-41 XP11
- ⑫ HAND SHOWER F907-41 XP12
- ⑬ HAND SHOWER CHECK VALVE F907-41 XP13

artos®

F907-41

CARE & MAINTENANCE

flexible hose shower kit with
slide bar and separate water
outlet squ

For best results, keep the following in mind to retain the high quality finish of your artos® shower kit:

- Use a soft, dampened sponge or cloth. On no account should you use an abrasive material such as a brush, scouring pad or steel wool to clean surfaces.
- Test your cleaning agent solution on an inconspicuous area before applying to the entire product.
- Wipe surfaces clean and rinse completely with water immediately after applying cleaning agent.
- An ideal cleaning technique is to rinse faucet thoroughly and blot dry any water from the surface after each use.

LIMITED LIFETIME WARRANTY

Artos® Limited Lifetime Warranty

Artos® faucets have been manufactured under the highest quality and manufacturing standards. Artos® faucets are guaranteed for life against leaks and manufacturing defects for as long as the original consumer purchaser owns it. This warranty applies to installations in the US, Canada and Mexico (North America). Commercial, Industrial or business uses are warranted for a period of one year from the original date of purchase.

This warranty is non-transferable and applies exclusively to the original owner or end-user. If a defect is found during normal use, Artos® will, at its election, repair, replace or make an appropriate adjustment. Damage caused by accident, misuse, abuse, improper installation or alteration will void the warranty. This warranty does not cover replacement parts where damage is caused by normal wear and tear. Labor charges, installation or other incidental or consequential costs will not be covered.

Replacement parts that qualify for warranty repair can be obtained by contacting Artos® at 1-877-9ARTOS9 or by e-mail at info@artos.us.com. Proof of purchase (original sales receipt) from the original consumer purchaser must accompany all warranty claims. When submitting your claim in writing, please provide your name, address and telephone number.

Please register this product online at WWW.ARTOS.US.COM

Item No : **F 907 -41**
Serial No :