# Page 1 of 2 Cutting Die 8/7/2018

34.5"

· ·	· ·	· ·		
1	1	1		
1	1	1		
1	1 1	I I		
1	' 	' 	<u>'</u>	
· 				
I	I	I	i	
I	I	I	I	5.75"
i I				
I and the second se	I and the second se	I and the second se	I .	
I and the second se	I and the second se	I and the second se	I .	
I and the second se	I and the second se	I and the second se	I .	
I and the second	I and the second	I and the second	I .	
I and the second	I and the second	I and the second	I .	
I	I	I	I	
I and the second	I and the second	I and the second	I	

	Notes Section:											
Rev	ECO/EN#	Completed By	Details/Description	MASCO CORPORATION PLUMBING PRODUCTS DIVISION	Do Not Scale, All Dimensions i Fractional Tol ±1/8" (± 2 mm) u For reference only, not for repr	nless specified otherwise	LINE TYPE	CUTTING DIE #	BOXES PER TIER XXXXX	BOXES PER PALLET  XXXXX	PART NET	T WEIGHT
Α		SR	INITIAL RELEASE	THIS DOCUMENT AND ALL THE DATA IT CONTAINS IS THE SOLE AND EXCLUSIVE PROPERTY OF DELTA FAUCET COMPANY, DIVISION OF MASCO			FOLDING	SCALE	CREATE DATE	PREPARED BY	APPROV	
В		JW	Text revision.	CORPORATION OF INDIANA AND SHALL NOT BE DISCLOSED TO OTHERS WITHOUT THE EXPRESS CONSENT OF DELTA FAUCET COMPANY.  COPYRIGHT © 2020 MASCO CORP. of INDIANA			REVERSE	("2:5")	05/28/2020	DMH	JW	/
С				MATERIAL	S 80# silk cover	OUTSIDE DIMENSION 5.75" x 34.5"	MATERIAL SIZE	JOINT METHOD none	PART DESCRIPTION  Marketing Insert	PART NUMBER 104180	REV. <b>B</b>	PAGE 1 of 2

# Page 2 of 2 Graphics Page 8/7/2018

# BEFORE YOU BEGIN.


These instructions begin with an installed Delta Touch 20° faucet. If you have not installed your faucet yet, please follow the instructions for faucet installation prior to installing your Delta VoicelQ<sup>TM</sup> Module. You will also need a smartphone or tablet and the following to complete the set-up:








## NOW, LET'S GET STARTED.







gently pulling it downward. Module unit onto the bottom of your existing solenoid.








VoicelQ™ Module and secure it with the retaining clip.



STEP 7: Connect the ethernet cable to the VoicelQ™ Module and the existing solenoid.

STEP 8: Connect the power supply to the solenoid and to an outlet that is not controlled by a switch. Reinstall Touch<sub>2</sub>0\* solenoid batteries.\* Turn on water supply and continue set up.



#### ACCESS THE WEB PAGE.



Connect your smartphone or tablet to your VoicelQ<sup>net</sup>
Module's Wi-Fi signal, "Delta-ABC." Your VoicelQ<sup>net</sup>
Module will have a unique identifier in the Wi-Fi
network name, shown here as "ABC."



Be sure to disconnect your smartphone or tablet from cellular data. Open a browser and enter the URL 10.10.10.1 for product setup. Follow the steps



Bookmark device.deltafaucet.com for easy access to the Web page, where you can see settings, FAQs, and a list of voice commands.

#### VOICEIQ™ MODULE LED COLOR INDICATORS

Look for this on your VoiceIQ™ Module under the sink, not at the faucet base.

BLINKING GREEN Setup Mode: Indicates the VoiceIQ<sup>™</sup> Module is ready to set up. Scan for Wi-Fi networks on your mobile device and connect to "Delta-ABC" ("ABC" is used here to mark your module's unique identifier code)

Blinks once every 5 seconds. This indicates that the required AC power is not connected.

SOLID GREEN

This indicates a successful connection to Wi-Fi

SOLID RED

This indicates an interrupted or failed Wi-Fi connection.

#### TROUBLESHOOTING TIPS

If your VoicelQ™ Module is blinking a red light every 5 seconds, there is an issue If your Voicela" Module is blinking a red light every 5 seconds, there is an issue with your power supply. Werly that the outlet you've pluged your module into isn't connected to your garbage disposal switch by plugging something else into the outlet (lamps and other lights work best, but anything that lights up or makes noise and doesn't have a backup battery will work), then switching your garbage disposal on and off. If the item plugged into the outlet only works with the garbage disposal switched on, your outlet is connected to your garbage disposal and isn't compatible with your VoicelQ" Module.

If you can't locate DELTA-ABC on your list of available Wi-Fi networks, check for a flashing green light on your VoiceIQ<sup>™</sup> Module under the sink. If the light is blinking green, re-scan for Wi-Fi networks on your mobile device. If the light is blinking red, see the above troubleshooting tip about power supply.

If the VoicelQ<sup>TM</sup> Module setup page fails to load on your mobile device after entering 10.10.10.1, check the following:

- a. If the LED light on your VoiceIQ™ Module is blinking green, it's still in Wi-Fi setup mode. Re-scan for Wi-Fi networks on your mobile device and connect to "Delta-ABC" ("ABC" is used here to mark your module's unique identifier code). b. If the LED light on your VoicelQ™ Module is blinking red, it isn't connected to a power source. See the first troubleshooting tip listed above.
- c. Turn off cellular data on your mobile device but leave Wi-Fi on, then refresh

the LED on the VoicelQ™ Module is solid red, check the following:

- a. Double-check that your Wi-Fi password was entered correctly.
- b. The VoiceIQ<sup>™</sup> Module works with 2.4 GHz Wi-Fi. If your router has both 2.4 GHz and 5.0 GHz, make sure you use 2.4 GHz. When scanning for Wi-Fi networks on your mobile device, only the 2.4 GHz network will appear.

### QUESTIONS?

..... о перь. rou II find a full list of frequently asked questions at device.deltafaucet.com. You're also welcome to call our customer solutions line at 877-652-8151.



Notes Section:											
COLOR #1	COLOR #2 MAGENTA	COLOR #3 YELLOW	COLOR #4 BLACK	COLOR #5 PMS 200 C	COLOR #6	COATING Coating Aqueous Silk	PRINTING -	PAGE 2 of 2			