

**\*\*\*READ & SAVE THESE INSTRUCTIONS \*\*\***  
**ACCESS LIGHTING**  
**MODEL # 50129**  
**INSTALLATION & OPERATION INSTRUCTIONS**

1) TOOLS AND MATERIALS REQUIRED

- ❖ Blade Screwdriver
- ❖ Star Screwdriver
- ❖ Wire Cutters
- ❖ Wiring supplies as required by Electrical Code
- ❖ Step Ladder

**Attention:**

**Before assembling your lighting fixture, please read the following instructions.**

(2) GENERAL

1. To ensure the success of the installation, be sure to read these instructions thoroughly before beginning.
2. All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.
3. These fixtures are intended for mounting to a standard 4" x 2 1/4" deep metal octagon outlet box. The box must be directly supported by the building structure and U.L. Recognized.
4. Before commencing with the installation, **disconnect the power by turning off the circuit breaker** or by removing the fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.

**NOTE:**

**The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that cannot be built into any product. The person(s) caring for and operating the fixture must supply these factors.**

(3) UNPACKING THE FIXTURE

On checking the contents of the box you will find;

1. Fixture assembly
2. Hardware Packet
3. 1 x Canopy
4. 1 x Flat Glass
5. 1 x Curved Glass
6. 14 x 40W HGN 120V/JCD G-9
7. 14 x Bulb Covers

(4) PREPARE THE FIXTURE

1. If you are replacing an existing fixture, disconnect and remove the old fixture. Expose the supply wiring from the outlet box.
2. Lay the un-assembled fixture on a soft surface and carefully remove all the packing material.
3. Prepare the fixture: Place the **Curved Glass (1)** over the **Canopy** and slide it down till it rests on the bottom of the fixture.
4. Insert the supplied **bulbs (2)** into the sockets.

**DO NOT EXCEED THE RECOMMENDED WATTAGE**

5. Place the supplied **clips and bulb covers (3)** onto all of the bulbs (2).
6. Slide the **Flat Glass (4)** over the **Canopy** and secure to the body of the fixture with the supplied **Brass Nuts (5)**.
7. Determine the desired length of your fixture and adjust the aircraft cable to the desired length by pushing on the **Grip Lock buttons** located on the **canopy**.
8. Attach the supplied **Crossbar** to the **J- box**, with the supplied **Mounting Screws (6)**.
9. Attach the **supply wires** to the **Fixture Wires**. The **Black supply wire** attaches to the **Black** fixture wire and the **White supply wire** attaches to the **White** fixture wire. Attach the **Green/Ground wire** from the fixture to the **Electrical Supply Wire** or to the **Green Screw** located on the **Mounting Plate**. Secure these connections with supplied **Wire Connectors (7)** and tape these connections with U.L. Listed electrical tape.
10. Tuck the wires carefully into the **J-Box**. Raise the **Canopy** to the ceiling and secure in place by screwing the supplied Screws into the holes located on the sides of the **Canopy**.
11. Restore electricity and enjoy your new lighting fixture.

**CAUTION:**

- **Ensure that the Fitting is Cool and Switched off, Before Changing Bulbs.**
- **Do Not use Bulbs Exceeding Maximum Wattage of 40w, As Per Caution Label.**
- **Do Not Touch the Bulb while fixture is in operation.**
- **Do not place fixture close to combustible material.**

**a c c e s s**

**L I G H T I N G**

**MODEL # 50129**

