# \*\*\*READ & SAVE THESE INSTRUCTIONS \*\*\* ACCESS LIGHTING MODEL # 52143 INSTALLATION & OPERATION INSTRUCTIONS

# 1) TOOLS AND MATERIALS REQUIRED

- Blade Screwdriver
- Star Screwdriver
- Wire Cutters
- Wiring supplies as required by Electrical Code
- Step Ladder
- ❖ 3 x G-9/40W Bulb

#### Attention:

Before assembling your lighting fixture, please read the following instructions.

### (2) GENERAL

- 1. To ensure the success of the installation, be sure to read these instructions thoroughly before beginning.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.
- These fixtures are intended for mounting to a standard 4" x 2 ¼" deep metal octagon outlet box. The box must be directly supported by the building structure.
- Before commencing with the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.

#### NOTE:

The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that cannot be built into any product. The person(s) caring for and operating the fixture must supply these factors.

# (3) UNPACKING THE FIXTURE

On checking the contents of the box you will find;

- 1. Fixture assembly
- Hardware Packet
- 3. Universal crossbar with U-shaped bar
- 4. 3 x Bulb Covers
- 5. 3 x Glass Shade
- 6. 3 x Glass Retaining Ring

# (4) PREPARE THE FIXTURE

- 1. If you are replacing an existing fixture, disconnect and remove the old fixture. Expose the supply wiring from the outlet box.
- 2. Lay the un-assembled fixture on a soft surface and carefully remove all the packing material.
- Attach the supplied Universal Crossbar to the J- box, with the supplied Mounting Screws.
- 4. Feed the Supply Wires through the hole in the Universal Crossbar and attach the Supply Wires to the Fixture Wires. The Black supply wire attaches to the Black fixture wire and the White supply wire attaches to the White fixture wire. Attach the Green/Ground wire from the fixture to the Electrical Supply Wire or to the Green Screw located on the Universal Crossbar. Secure these connections with supplied Wire Connectors and tape these connections with U.L Listed electrical tape.
- 5. Insert the two supplied Screws into the holes in the U-shaped Bar that is attached to the Universal Crossbar. Attach the Fixture Canopy to the Universal Crossbar by positioning the Fixture Canopy such that the two screws from the U- Shaped Bar slide down into the slots in the canopy. Now twist the canopy so that the screws move into the vertical slots. Tighten the Screws down to secure.
- Slide each Glass Shade over each socket and secure with the supplied glass retaining rings.
- 7. Insert the supplied **G9/40W Bulbs (9).** <u>Do not exceed wattage</u> <u>as stated on warning label.</u>
- 8. Secure the supplied **Bulb Covers** onto the **sockets**.
- The height of your fixture can be adjusted by loosening the knurled nuts on the rods and gently moving the inner rods to the desired length (not to exceed overall height of 50")
- 10. Restore electricity and enjoy your new lighting fixture.

# **CAUTION:**

- > Ensure that the Fitting is Cool and Switched off, Before Changing Bulbs.
- Do Not use Bulbs Exceeding Maximum Wattage of 40w, As Per Caution Label.
- > Do Not Touch the Bulb while fixture is in operation.
- Do not operate fixture next to combustible material.



# MODEL:#52143 Joint Box Live Wire Earth Wire Neutral Wire Canopy Glass Shade Socket Ring G9 Bulb Max 40W (Included) Protective Glass