

## **INSTALLATION INSTRUCTIONS**


### **Parts Included**

- 4 Cone Washers • 2 Plated Locknuts • 2 Supply Tubes •
- 2 Escutcheons • 2 Brass Locknuts •

### **Tools Needed**

- Adjustable Wrench • Set of Crescent Wrenches • Pliers • Teflon Tape (use as a sealant on all male threaded tubing) •

**This water supply tube kit includes the parts listed above ONLY. The faucet must be purchased separately.**



### **To Assemble Tubes**

1. First be sure to shut off the the water supply. Remove old water supply tubing. Put a cone washer, with the wide end of the washer inward, onto the upper end of each supply tube.
2. Slide a plated locknut up to the top of each supply tube.
3. On the bottom of each supply tube, slide one of the escutcheons up the tube partway, then slide the brass locknut onto the end of each tube directly under the escutcheon.
4. Put another cone washer with the wide end of the washer downward onto the bottom end of the tube.

### **To Install Supplies**

1. Attach the bottom end of each supply tube to the water supply in your floor by screwing the brass locknut down tightly. Let the escutcheons slide down to the floor.
2. Attach the upper end of one supply tube to the “cold side”, faucet connection tube located under the rim of your tub by inserting the supply tube into the faucet connection and tightly screw the decorative locknut over the two for a tight fit.
3. Repeat steps 1-2 using the other supply tube and connecting it to the “hot side” faucet connection.
3. Test all threaded connections for leaks. Re-thread connections using teflon tape to prevent leaks if necessary.

**NOTE: Please seek professional help if you have copper plumbing in your home.**

### **Cleaning Instructions**

Wipe this whole set off with warm water and a soft cloth. DO NOT use soaps, cleansers, or brass cleaners as they will disintegrate the protective lacquer coating and leave the brass exposed causing it to tarnish.