



Plus:
 • 3/16" Masonry Bit
 (For Concrete Installation)

<p>Record your model number.</p> <p>NOTICE: Adequate floor support is required. A wood support must be a minimum of 2" (51 mm) thick by 6" (152 mm) wide. Standard 2x6 lumber is NOT sufficient for this application. Concrete can be used as the floor support. Observe all local plumbing and building codes.</p>	<p>1 Roughing-In</p>	<p>2 Roughing-In</p>	<p>3 Construct a wood support under the floor according to the roughing-in dimensions.</p>
<p>4 Verify correct spout orientation before installing the base. The base has a notch on the cold supply side.</p>	<p>5 Use the base to mark the mounting holes on the wood support.</p>	<p>6 Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p>	<p>7 Secure the base to the support with the screws and washers.</p>
<p>9 Insert the plug into the base. Turn on the water and check for leaks.</p>	<p>10 Turn off the water and secure the guard onto the base.</p>	<p>11 Finish the floor, leaving a 3" (76 mm) diameter hole for the guard.</p>	<p>12 Cut the guard flush with the finished floor.</p>
			<p>13 Install the faucet according to the manufacturer's installation instructions.</p>

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.