



# KALLISTA® Kallista Contemporary Toilet Supply Line & Kallista Traditional Toilet Supply Line

---

## INSTALLATION INSTRUCTIONS



**P21637**



**P21643**

# KALLISTA® Kallista Contemporary Toilet Supply Line & Kallista Traditional Toilet Supply Line

## INSTALLATION INSTRUCTIONS

### THANK YOU FOR CHOOSING KALLISTA

We appreciate your commitment to Kallista quality products. Please take a moment to review this manual before you install your Kallista product. If you encounter any installation or performance problems, please do not hesitate to contact us at the phone number listed at the bottom of the page.


### TOOLS



Thread Sealant



Strap Wrench



Adjustable Wrench

### BEFORE YOU BEGIN

**CAUTION: Risk of product damage.** Do not kink or cause damage to the supply tube during installation.

- Observe all local plumbing and building codes.
- Turn off the main water supplies.
- Kallista reserves the right to make revisions in the design of products without notice, as specified in the Price Book.

### 1. INSTALL THE SUPPLY AND STOP

- Wrap thread sealant tape around the threads of the valve body assembly.
- Slip the escutcheon over the threaded end of the valve body assembly. Thread the valve body assembly into the water supply.
- Tighten with a clean strap wrench, making sure the water outlet on the body assembly is facing straight up.
- Remove the shroud from the water outlet and set aside.
- Determine the length of the supply tube by measuring from the top of the water outlet to the bottom of the toilet valve, and add 3/4". Carefully cut the supply tube to the required length, being careful not to compress the tube. Remove any burrs from the cut end.
- Remove the nut from the toilet valve and slide it onto the supply tube. Slide the shroud onto the supply tube.
- Loosen the nut on the valve body assembly outlet and insert the plain end of the supply tube. Tighten the nut with a wrench.
- Align the top of the supply tube with the bottom of the toilet valve (the supply tube can be bent slightly), and thread the toilet valve nut onto the toilet valve.
- Turn on the main water supply. Turn the valve handle to the left. Check for leaks and repair as necessary.
- Slide the shroud over the valve body assembly outlet.
- Slide the escutcheon so that it meets the wall. Apply a bead of silicone sealant or caulk if desired.

