

SUPPLY LINES INSTALLATION GUIDE

BEFORE YOU BEGIN

- 1) Verify the center to center of your faucet and rough in your supply lines accordingly, flush lines to clear any debris left in the lines.
- 2) Allow a 6" minimum clearance below the floor to allow sufficient space for attachment of supply lines to the intended stub out.
- 3) Drill 1" holes at the rough in location.
- 4) We recommend that you install 3/4" brass floor flanges (not include) from below as an extra support.

INSTRUCTIONS

- 1) Insert flange on bottom risers, thread top locknut and rubber washer and insert from above, through the brass flange if you elected to install one under the floor.
- 2) Secure from below by inserting metal washer and threading the lock nut.
- 3) Apply Teflon tape to the top and bottom threads of the lower riser and thread the supply lines to the supply line to the lower riser.
- 4) Thread hot and cold shut-off valve to the top of lower riser.
- 5) Insert washer and coupling nut into the riser.
- 6) Apply Teflon tape to bottom threads of the top riser and thread onto the shut-off valve..
- 7) Placing a bucket underneath the supply line outlets turn on hot and cold valves, this will help clear debris from the line as well as give you opportunity to check for leaks.



COMPLETE INSTALLATION

Note: Don't over tighten the pipes to avoid damage.

TOOLS AND MATERIALS



**** This item is designed to be installed in wood floors. If you have a concert floor it may be necessary to build a platform to accommodate the inlet connections refer to image as below.**



TUB FAUCET INSTALLATION GUIDE

BEFORE YOU BEGIN

1. Shut off water supply.
2. Carefully inspect waste and supply tubing for signs of damage.
3. Replace waste or supply tubing if necessary

TOOLS AND MATERIALS




INSTRUCTIONS


1. Apply tape or putty to both ends of hot and cold supply nipples (8). Thread the nipples into couplers (7).
2. Attach the rubber washer into coupler nut, connect with faucet body (5).
3. Set the faucet onto tub and nipples go through the tub wall holes.
4. Slide the metal washer (9) and install the lock nut (10) tighten with wrench.
5. Set the handles (6) on faucet body with screws.
6. Attach the cradle (4) to faucet body with rubber washer.
7. Attach the shower hose (3) to cradle with rubber washer.
8. Connect the water supply lines to coupler nipples.
9. Turn on the water supply and open the faucet valves. Check for any leaks. If leakage occurs, tighten connections again as necessary. Let the water flow through the shower hose for approximately 30 seconds to clear out debris and dirt.
10. Connect the hand-held shower (1)(2) with shower hose and check leaks.

COMPLETE INSTALLATION

Note: All connections nuts, do not tighten more than 1/4 turn beyond hand tight.



WALL MOUNT



DECK MOUNT

