



Freestanding Tub with Faucet Installation Guide


Caution

- Carefully read the instructions before starting the installation.
- This bathtub should be installed by an experienced plumber.
- You will need at least two people to install this product properly.
- In order to reduce the risks of personal injuries, do not support or lift the bathtub by the rim. Provide adequate support under the feet.
- Manufacturer is not responsible for any damage to the unit or personal property caused by improper installation. If you disregard instructional warnings, you will void your warranty.
- Unpack and inspect the bathtub for damage. Return the bathtub to the carton until you are ready to install.
- Install the bathtub on an adequately supported, level floor.
- Before installation, ensure proper access to the final plumbing connection.
- Drain waste vent must always be installed according to local standard. Verify the placement of the bathtub before drilling the hole for the drain waste vent.
- Confirm and inspect the Tub & Faucet within 48 hours
- Confirm the existing hot water and cold water supply lines are installed with 3/4" NPT pipe connection fitting adapters

Faucet Installation Manual

Included In Roman Bathtub Faucet Box:

- 1 pcs: Mixing Valve Complete (1)
- 1 pcs: Spout / Diverter Complete (8)
- 1 pcs: Handheld Shower Complete (21)
- 3 pcs: Rubber Gaskets (3 & 14)
- 3 pcs: Steel Washer & Long Nut (4, 5 & 15)
- 1 pcs: Split Locking Nut w/ locking Screws (16 & 19)
- 1 pcs: Hose Weight (24)3 Pcs: Chrome Flange w/ Gasket (11A, B & C)



1. **Tub Drilling Procedures Components:** Mixing Valve (1), Water Spout (8), Handheld Shower Head (21) Locate on top of the tub rim the 3 bathtub faucet component to be installed. Using masking tape, layout on the tub rim all three 1-1/2" diameter holes to be drilled.

Note: Centerline Dimensions as shown are for suggestion only.

2. **Installing The Mixing Valve (1)** Slip the Chrome Flange & Gasket (11A) over the Water Supplies (6) and Connector Hose (7) and onto the threaded extension. Insert the Mixing Valve (1) through the first hole on the left. From underside slip the Rubber Washer (3) and Plastic Washer (4). Screw the Lock Washer w/ Set Screws (16 & 19) onto the threaded extension and adjust to 1/8" below Plastic Washer(4) and tighten Set Screws (19). Note: Before tightening the Mixing Valve down completely, make sure it is properly located and aliened with the tub.

Contact Maidstone for additional information and specifications. For complete warranty information and a list of dealers visit www.MaidstoneSupply.com. All products and specifications are subject to change without notice. Maidstone is not responsible for typographical and/or dimensional errors. Typographical errors are subject to correction.

Note: Rough-in dimensions may vary +/- 1/2" and are subject to change. No responsibility is assumed by Maidstone.



Freestanding Tub with Faucet Installation Guide

3. **Installing The Water Spout & Diverter Valve (8)** Slip the Chrome Flange & Gasket (11B) over the Flexible Water Supplies. Insert the Water Spout & Diverter Valve (8) through the middle hole. From underside slip the U Rubber Washer (14) and U Metal Lock Washer (3) onto the $\frac{1}{4}$ " threaded rod. Screw on the Long Nut (5) and tighten. Note: Before tightening the Water Spout & Diverter Valve down completely, make sure it is properly located and aliened with the tub.
4. **Installing The Handheld Shower Spray (21)** Slip the Chrome Flange & Gasket (11C) over the threaded extension and Shower Hose and set against base. Insert the Hand Held Shower Spray (21) through the right hole. From underside slip the Rubber Washer (14) slip the Metal Locking Nut (?) and tighten .Install the handheld shower hose Weight (24) onto the Handheld Shower Spray Hose (20).Note: Before tightening the Water Spout & Diverter Valve down completely, make sure it is properly located and aliened with the tub.
5. **Water Connections** Connect Mixing Valve Braided Hose (7) to Water Spout Braided Hose (20) and tighten. Connect Hand Held Shower Spray Braided Hose (21) to Water Spout Braided Hose (12) and tighten Connect both Mixing Valve $\frac{3}{4}$ " Hot Water & Cold Water Braided Hoses (6) to the existing hot water & cold water supplies (supplied by others) and tighten snug.

Tub Installation Manual

1. Remove the bathtub from its carton and place it on a throw rug or other protective floor covering material to prevent damage to the bathtub or floor.
2. Position the tub in its final location and trace its outline with a pencil.
3. Position a clean drop cloth or similar material in the bottom of the bathtub. Be careful not to scratch the surface of the bathtub.
4. Level the bath by turning the leveling feet at the bottom of the tub. (You will need two people to manage this task)
5. If drain waste vent is not directly below the drain please use an adjustable flex pipe (not included) and follow steps 6-10 otherwise if not please continue down to straight drain installation steps 11.

Using Flex Pipe

6. Place tub on its side and connect flex pipe to the Tub drain pipe using the lock nut connector.
7. Arrange the flex pipe and connect its end to the waste vent. (use PVC cement to connect)
8. Flip over the bathtub.
9. Fill the bathtub to the overflow and check for leaks.
10. Affix the bathtub by applying silicone on the contour of the base. Let dry 24h.

Straight drain Installation (not included)

(Requires a RapidConnect Drain *sold separately OR access below the floor, OR must be built on a platform)

11. Connect the drain directly to the drain waste vent. (Straight drain tail piece not included)
12. Flip over the bathtub.
13. Fill the bathtub to the overflow and check for leaks
14. Affix the bathtub by applying silicone on the contour of the base. Let dry 24h.

Contact Maidstone for additional information and specifications. For complete warranty information and a list of dealers visit www.MaidstoneSupply.com. All products and specifications are subject to change without notice. Maidstone is not responsible for typographical and/or dimensional errors. Typographical errors are subject to correction.

Note: Rough-in dimensions may vary +/- 1/2" and are subject to change. No responsibility is assumed by Maidstone.