

## PRODUCT SUBMITTAL 220

**Product:** PRO-BALANCE<sup>®</sup> Flow-Stop Circuit Valve

**Date:** 22-July-09 (supersedes, 20-September-07)



Article No.	Description
250224	PRO-BALANCE Flow-Stop Circuit Valve

### TECHNICAL DESCRIPTION

Material	Brass
Unit Weight	0.29 lb (0.13 kg)

### FUNCTIONAL DESCRIPTION

This brass 1/4 turn ball valve attaches to R-20 circuit outlets on the supply side of PRO-BALANCE manifolds to allow for complete shut-off.

### INSTALLATION

Install Flow-Stop valves by hand onto R-20 circuit outlets of the PRO-BALANCE manifold. Do not use pipe dope or thread sealant. Thread the valve clockwise **BY HAND** until it stops. If necessary, back the valve off to align the valve stem with the front of the manifold. No tightening with a wrench is necessary, as the integral O-ring makes the seal. Overtightening may cause a leak – do not overtighten.

For updates to this publication, visit [na.rehau.com/resourcecenter](http://na.rehau.com/resourcecenter)

The information contained herein is believed to be reliable, but no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for particular applications or the results to be obtained therefrom. Before using, the user will determine suitability of the information for user's intended use and shall assume all risk and liability in connection therewith. To the extent permitted by law, REHAU EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE.

© REHAU Incorporated 2009